

7-12-19

## **Clean Speed KTM690/Husqvarna 701 Brake Pedal – 2011 and up**

### Installing the Brake Pedal

1. Remove the right-side footrest bracket assembly from the bike.
2. Remove the return spring and master cylinder push rod clevis bolt.
3. Remove the OEM brake pedal.
4. Mount the CSE pedal. Apply Loctite and torque the pedal pivot bolt per the factory specifications.
5. NOTE: 2016-2019 have a washer between the outer bearing and footrest bracket. Make sure the washer remains in place during reassembly.
6. Check for free movement of the pedal before reattaching the return spring. If the pedal doesn't move freely, remove it and check for any high spots in the foot rest bracket around the pivot hole. We have relieved the brake pedal to clear this area, but there may be imperfections in the factory casting. Do not proceed unless the pedal moves freely.
7. Attach the return spring and master cylinder push rod per factory specifications.
8. Reattach footrest bracket to the motorcycle following the factory recommendations.
9. Once everything is together, make sure that the rear brake line is routed correctly and nothing interferes with the brake pedal mechanism. With the bike on a stable stand spin the rear wheel by hand to make sure it moves freely. Apply the rear brake by hand to verify it stops the rear wheel rotation.

Clean Speed Engineering (CSE, Clean Speed) LLC is not responsible for any issues resulting from the use of our products.